



Model
F3ZN-S□□□□P09-□□

AREA SCANNER

When using F3ZN-S series as an area scanner,a controller(F3ZP)is required. You can also use F3ZN-S series as an area sensor without a controller.


INSTRUCTION SHEET

OMRON EUROPE B.V. (Representative in EU)
Wegalaan 67-69, 2132 JD Hoofddorp
The NETHERLANDS

(Note)
Connection with a setting console(F39-MC11) is possible for F3ZN-S series.However, when you use setting console before December 2001,the formal display in the screen is not F3ZN series.But it can be used satisfactory.
Moreover, combined use connection of a setting console and a area scanner controller cannot be performed.


©OMRON Corporation 2001 All Rights Reserved.

I/O CIRCUIT




Note: Be sure to use it in Open mode.

TIMING CHART



EXTERNAL DIAGNOSIS FUNCTION

- It is the function to stop emitting when the external diagnostic input is connected to +24V.
- The timing chart of the external diagnostic function. (in case of stable light reception)



Series connection

- Sensors can be connected in series using the types supplied with the connector for the series connection. Both the stand-alone type and the series connection type can be used for the sensors at the top end. (The F3ZN-SxxxxP09 series can connect with the F3ZN-SxxxxP09 series only.)
- No. of series connected light curtains : Up to 3 sets
- No. of beams : Up to 240 beams
- Length of the series connection cable : 3m max.

INDICATORS

Emitter	Receiver
① ~ ⑤	① ~ ⑤
Light intensity level indicator (green)	
①	:200%and above of ON threshold level
②	:150 to 200% of ON threshold level
③	:100 to 150% of ON threshold level
④	:75 to 100% of ON threshold level
⑤	:50 to 75% of ON threshold level
⑥ ~ ⑧ Error mode indicator (red) (refer to an attached Error Code Label)	
⑨	⑨ Output2 operating indicator (orange)
⑩	⑩ Output1 operating indicator (orange)
⑪	⑪ Power indicator (green)
⑫	⑫ Function indicator (green)

Place the sensor in the state where all light intensity level indicator are ON.

PROPER USE

- Connections**
- In case of F3ZN is switched on with the following mis-wiring states, notice that the F3ZN will not function properly WITHOUT error indication.
 - RS-485(A) and / or RS-485(B) is / are not connected between sensor emitter and sensor receiver, or
 - Control output2 is directly connected to +24V line or shield line.
- Lay the area sensor cable in an independent conduit tube or away from any high-tension cable or power line. Otherwise the sensor cable may be exposed to induction, resulting in malfunction or damage.
- Use the shielded extension cable of over 0.3mm², if required. Connect the shield line to 0V line. Do not extend the cable longer than 100m.
- Be sure to have a bend radius of R36 or more.
- Do not use a hammer or the like in setting up the sensor. Its internal circuitry might be damaged.
- Combined use connection of a setting console and a area scanner controller cannot be performed.

Power supply

- Ground the FG(frame ground)terminal and the G (ground) terminal when a commercially available switching regulator is used. If not grounded, switching noises may cause malfunction.

RATINGS

Ratings in only F3ZN-S

Model	F3ZN-SxxxxP09-xx (refer to nomenclature)			
No. of beams	21 to 125 (every two axes)			
Sensing width	180 to 1116mm (Sensing widths = 9 × Number of beams-1)			
Beam gap	9mm			
Detection capability	Opaque material 14mm dia.			
Operating range	0.2 to 7m			
Current consumption	Emitter : 170mA max. Receiver : 120mA max. (under no-load conditions)			
Light source	Infrared LED (870nm wavelength)			
Response time	Sensing width	0180 to 0441mm	0450 to 0756mm	0765 to 1071mm
	Output1	toff : 10ms ton : 40ms	12.5ms 50.0ms	15ms 60ms
Response time	Output2	toff : 50ms ton : 20ms	62.5ms 25.0ms	77.5ms 31.0ms
	Power supply voltage	24V DC ± 10% (ripple range(p-p):10% max.)		
Output	PNP transistor output,24V DC,load current 50mA Operating mode : Output1 Light ON / Output2 Dark ON (default)			
External diagnosis input	Open or 0 to 1.5V DC for inactive(emitting) 9 to 24V DC(3mA max.short-circuit current) for active (emitting OFF)			
Indicator	Emitter	Light intensity level indicator (5-bar, green LED) :Lit according to light intensity level Error mode indicator (3-bar, red LED) :Lit according to error condition Power indicator (green LED) :Lit during power-on		
	Receiver	External diagnosis indicator (orange LED) :Lit when EXternal diagnosis function is active Light intensity level indicator (5-bar, green LED) :Lit according to light intensity level Error mode indicator (3-bar, red LED) :Lit according to error condition Output1 operating indicator(orange LED) :Lit when Output1 is in ON-state Output2 operating indicator(orange LED) :Lit when Output2 is in OFF-state (default) Power indicator (green LED) :Lit during power-on Function indicator (green LED) :Lit when optional function is set		
Protection circuit	Reversed polarity protection,Output short circuit			
Ambient temperature	During operation :-10 to +55 deg Centigrade (with no freezing) During storage:-30 to +70 deg Centigrade			
Ambient humidity	During operation:30 to 95%RH (with no condensation) During storage:30 to 95%RH			
Ambient light intensity	Incandescent lamps :3,000lux max.(receiver surface light intensity) Sunlight :10,000lux max.(receiver surface light intensity)			
Degree of protection	IP65 (IEC60529)			
Weight	*Packaged Weight (g)=(Protective height + 100) × 2 + 1700) max.			
Accessories	Instruction manual, Mounting brackets(top and bottom), Mounting brackets(intermediate)*1, Error mode label			

*1 : Type which have the total length of the sensor over 612 mm : 1 set for each of emitter and receiver

WIRING PROCEDURE

- Connect the emitter extension cable (F39-JCxA/B-L, gray color outer jacket, order separately) to the emitter.
- Connect the receiver extension cable (F39-JCxB/D, black color outer jacket, order separately) to the emitter.

Connector

Front View	Pin No.	Signal Name		Wire Color of Extension Cable
		Receiver	Emitter	
	1	-	-	White *1
	2	24VDC	24VDC	Brown
	3	Output1	External diagnosis input	Green
	4	Output2	N.C.	Yellow
	5	RS-485(A)	RS-485(A)	Grey
	6	RS-485(B)	RS-485(B)	Pink
	7	0V	0V	Blue
	8	N.C.	N.C.	Red

*1 : Be sure to use it in Open mode.

ACCESSORY

Single-ended connector cable(F39-JCxA)

order separately

Type(set name)	for Emitter	for Receiver	L(mm)
F39-JC3A	F39-JC3A-L	F39-JC3A-D	3,000
F39-JC7A	F39-JC7A-L	F39-JC7A-D	7,000
F39-JC10A	F39-JC10A-L	F39-JC10A-D	10,000
F39-JC15A	F39-JC15A-L	F39-JC15A-D	15,000


Double-ended connector cable for Series Connection, Extension and F3ZP Connection(F39-JCxB)

order separately


Type(set name)	for Emitter	for Receiver	L(mm)
F39-JCR2B	F39-JCR2B-L	F39-JCR2B-D	200
F39-JC3B	F39-JC3B-L	F39-JC3B-D	3,000
F39-JC7B *1	F39-JC7B-L	F39-JC7B-D	7,000
F39-JC10B *1	F39-JC10B-L	F39-JC10B-D	10,000
F39-JC15B *1	F39-JC15B-L	F39-JC15B-D	15,000

*1 : [Note] Do not use for series connection.

Mounting Bracket (Top and Bottom)




Mounting Bracket (Intermediate)




MOUNTING BRACKET INSTALLATION

Mounting Bracket (Top and Bottom)




Mounting Bracket (Intermediate)




DIMENSIONS (The case of F3ZN-SxxxxP09)

Rear Mounting



Side Mounting



Dimensions for each type are calculated by following formulas.

F3ZN-MxxxxP09 : xxxx = 0180 to 1116 = C(Sensing width)

A = C + 95

B = C + 63

D = C + 31

F = Refer to the following table

Type that the intermediate mounting bracket and the mounting

F3ZN-SxxxxP09	The number of intermediate mounting brackets	Dimension F (note)
0612 to 1116	1	F=B/2

note:When not using value F obtained by the above-mentioned calculation, it gives as F= 670mm or less.

NOMENCLATURE

形F3ZN-S□□□□P09-□□

① Protective height(mm)

② P : PNP output type

③ Beam gap(mm)


④ Blank:Set of emitter and receiver

L:Emitter, D:Receiver

⑤ Connection method

	Connection with main system	Series connection	Below No.
Blank	Connector	-	-
01	Connector	Connector	A
02	Cable with connector	-	B
03	Cable with connector	Connector	A,B
04	Cable with connector	Cable with connector	B,C
05	Connector	Cable with connector	C

(The different outside and size with F3ZN-SxxxxP09)



This device can not be used as a safety device to prevent personal injury by placing hands or other parts of body in hazardous area, an intrusion prevention device.

- Do not use as a safety device to prevent personal injury by placing hands or other parts of body in a hazardous area.
- Do not use on a machine or any devices as a safety interlock.
- Do not use on a machine or any devices as a safety mechanism or as an emergency stop for machines or devices when hands or other body parts enter a hazardous area.
- Do not use on an intrusion prevention device to open and shut a door or a window to hazardous area by detecting person's hand or other parts of body.
- This is a class A product. In residential areas it may cause radio interference. in which case the Responsible Person may be required to take adequate measures to reduce interference.